

 LABORATOIRES Prodene Klint Division lingettes 8, rue Léon Jouhaux ZA PARIEST F-77183 CROISSY BEAUBOURG	TECHNICAL DATA SHEET FINISHED PRODUCT	Approval: 
	File:n:\fichword\vio\fiches\techniq FTL243-GB.DOC	Revision : 01/15.05.08 Page: 1/2

SHEET NO. U L243-GB KLINT FORCE

DEFINITION:

KLINT FORCE are wipes made of a non-woven material, permeated with a cleansing solution for the hands and surfaces.

COMPOSITION:

Wipe permeation solution: Ingredients

Aqua, PEG-40 Hydrogenated Castor Oil, , Dimethyl Glutarate, , Laureth-11, D-Limonene, Dimethyl Succinate, Parfum, Dimethyl Adipate, Lauramine Oxide.

Bonded web: Cellulose/polypropylene, with an abrasive side

USE:

KLINT FORCE is a non-woven wipe, slightly abrasive for stripping, impregnated with a very powerful cleaning solution (alcohol-free) that eliminates most soiling.

The wipe are a modern mean to quickly clean the hands without water or soap and without leaving one's station. Simply rub the wipe over the hands or on the object to be cleaned until the soil disappears and let dry.

The wipe can be used everywhere, at factory workstations, on work sites, in a garage, on the road, at the farm, camping, while gardening or for handiwork around the home.

The wipe clean and de-grease hands, objects, machines.

The wipe remove oil, grease, tar, glue, fresh paint, printing inks, writing inks, felt-tip marker inks, toner, the smell of petrol or diesel fuel etc.

The wipe have a pleasant citrus scent.

DIRECTIONS FOR USE :

Pull a wipe HORIZONTALLY until the dotted line appears. Separate with a quick pull. If the next wipe does not follow, open the package and pull the next wipe in the center of the roll. Carefully close the package after use to avoid drying out the wipe.

Rub the wipe on the surface to be cleaned until the soiling disappears. Use several wipes if necessary. Do not rinse. Let dry.

Throw used wipe in a waste bin.

PRECAUTIONS FOR USE:

Use extern only, this product is reserved for cleaning hands and objects.

Do not swallow.

Keep out of reach of children.

 LABORATOIRES Prodene Klint Division lingettes 8, rue Léon Jouhaux ZA PARIEST F-77183 CROISSY BEAUBOURG	TECHNICAL DATA SHEET FINISHED PRODUCT	Approval: 
	File:n:\fichword\vio\fiches\techniq FTL243-GB.DOC	Revision : 01/15.05.08 Page: 2/2

TOLERANCE OF PERMEATION SOLUTION

Hypoallergenic solution: formulated to minimize the risk of allergy.

COMPATIBILITIES:

The product is compatible with most materials; nevertheless run a preliminary test.

INCOMPATIBILITIES:

Do not mix with other products..

CONSERVATION:

The wipes may be stored for 30 months away in normal temperature conditions.

OTHER INFORMATION:

The information contained in this document is based on our present knowledge related to the concerned product and have no other purpose than to provide information on our products and their application possibilities. This information complies with current legislation and is given in good faith. It in no way may constitute a commitment by us on the specific properties of these products or their application for a given use. The users' attention is, in addition, drawn to the risks that may be encountered when the product is used for purposes other than those for which it was designed.